


ASSEMBLY INSTRUCTIONS:

ITEM NO: BO-2444FL

1. Carefully unpack and lay out the parts as shown in illustration.
 2. Screw the tube(B),tube(C), soft tube section(D) into the base section(A) respectively, then pull the cord from base.
 3. Place the shade(E)onto the soft tube section(D), and tightening it by ring(F),then adjust the shade in balance..
- Notice: The soft tube section (D)should be adjust in certain position; if the lamp working at a long time, please don't put shade in horizontal position.(as the picture shown).



Your lamp now is ready to enjoy

**Use 2*40 Wattage (Maximum)
Type A bulb(Bulb not included)
3-Way Rotary Socket Switch**

The wrong position of soft tube section

IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

328185B